

INTRODUCTION

The device is a single door multifunction standalone access controller or a Wiegand output reader. The operation is very user-friendly, and low-power circuit makes it long service life.

Features

- > Metal case, anti-vandal
- > Waterproof, conforms to IP65
- > Video calling based on WiFi
- > Full duplex voice intercom
- > One relay, 1,000 users (990 common + 10 visitor)
- > PIN length: 4-6 digits
- > Card type: 125KHz EM Card/13.56MHz Mifare Card
- > Can be used as Wiegand reader with buzzer output
- > Card block enrollment
- > Tri-color LED status display
- > Pulse mode, Toggle mode

Specifications

User Capacity Common User Visitor User	1000 900 (Fingerprint version support 100 fingerprints) 10
Operating Voltage Working Current Idle Current	12-18V DC ≤150mA ≤60mA
Proximity Card Reader Radio Technology Read Range	EM/Mifare 125KHz /13.56MHz 2-5 cm
PIN Length	4-6 digits (Keypad version only)
Wiring Connections	Relay Output, Exit Button, Wiegand Input, Wiegand Output
Relay Adjustable Relay Output Time Lock Output Load	One (NO, NC, Common) 0-99 Seconds (5 seconds default) 2 Amp Maximum
Wiegand Interface	EM card: Wiegand 26-44 bits input & output. Mifare card: Wiegand 26-44bits 56bits, 58bits input & output. (Factory default: Wiegand 26bits for EM card, Wiegand 34bits for Mifare card) 4 bits, 8 bits(ASCII), 10 digits Virtual Number (Factory Default: 4 bits)
PIN Output	

- 01 -

Environment Operating Temperature Operating Humidity	Meets IP65 -40°C~60°C(-40°F~140°F) -30°C~60°C(-22°F~140°F) Fingerprint only 0%RH~92%RH
Physical Colour Dimensions Unit Weight Shipping Weight	Zinc-Alloy Silver & Black 142 x 48 x 22mm 315g 410g

Carton Inventory

INSTALLATION

- > Remove the back cover from the unit
- > Drill 2 holes(A,C) on the wall for the screws and one hole for the cable
- > Knock the supplied rubber bungs to the screw holes(A,C)
- > Fix the back cover firmly on the wall with 4 flat head screws
- > Thread the cable through the cable hole(B)
- > Attach the unit to the back cover

- 02 -

Wiring

Wire Color	Function	Notes
Red	DC +	12-18V DC Power Input
Black	GND	Negative Pole of DC Power Input
Blue	Relay NO	Normally Open Relay Output (install diode provided)
Brown	Relay Common	Common Connection for Relay Output
Grey	Relay NC	Normally Closed Relay Output (install diode provided)
Yellow	OPEN	Request to Exit(REX) Input
Green	Data 0	Wiegand Output (Pass-through) Data 0
White	Data 1	Wiegand Output (Pass-through) Data 1

Sound and Light Indication

Operation Status	LED	Buzzer
Stand by	Red light bright	—
Enter into programming mode	Red light shines	One beep
In the programming mode	Orange light bright	One beep
Operation error	—	Three beeps
Exit from the Programming mode	Red light bright	One beep
Open lock	Green light bright	One beep
Alarm	Red light Shines quickly	Beeps

Basic Configure

Enter and Exit Program Mode

Programming Step	Keystroke Combination
Enter Program Mode	* (Master Code) #
Exit Program Mode	*

Set Master Code

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Update Master Code	0 (New Master Code) # (Repeat New Master Code) # (Master code is any 6 digits)
3. Exit Program Mode	*

- 03 -

Set the Working Mode

Notes: The device has 3 working modes: Standalone Mode, Controller Mode, Wiegand Reader Mode, choose the mode you use. (Factory default is Standalone Mode / Controller Mode)

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Standalone/Controller Mode OR 2. Wiegand Reader Mode	7 7 # (Factory default) 7 8 #
3. Exit	*

STANDALONE MODE

The device can work as Standalone Access Control for single door. (Factory default mode) — 7 7 #

Connection Diagram

Common Power Supply

- 04 -

Access Control Power Supply

Programming

Programming will be very depending on access configuration. Follow the instructions according to your access configuration.

Notes:

- > **User ID number:** Assign a user ID to the access fingerprint/ card/ PIN in order to track it.

The Common User ID:
 Fingerprint version: - Fingerprint user ID: 0 ~ 98
 Card user ID: 100 ~ 989
 Master Fingerprint User ID: 99
 Visitor User ID: 990-999

Other two versions:
 - PIN/Card User ID: 0-989
 - Visitor User ID: 990-999

IMPORTANT: User IDs do not have to be proceeded with any leading zeros. Recording of User ID is critical. Modifications to the user require the User ID be available.

- > **Proximity Card:** Proximity Card: 125KHz EM card/13.56MHz Mifare Card
- > **PIN:** Can be any 4-6 digits except 8888

- 05 -

Add Common Users

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #

Add Fingerprint User (Fingerprint version only)

Programming Step	Keystroke Combination
2. Using Auto ID (Allows the device to assign Fingerprint to next available User ID number)	1 (Fingerprint) (Repeat Fingerprint) (Repeat Fingerprint again)
OR	2. Select Specified ID (Allows Master to define a specific User ID to associate the fingerprint to)

Add Card User

Programming Step	Keystroke Combination
2. Using Auto ID (Allows the device to assign Card to next available User ID number)	1 (Read Card) / (Input 8/10/17 Digits Card Number) #
OR	2. Select Specific ID (Allows Master to define a specific User ID to associate the card to)
OR	2. Add Card: Block Enrollment (Allows Master to add up to 890 cards to the Reader in a single step) Takes 2 minutes to program.

Add PIN User (Keypad version only)

Programming Step	Keystroke Combination
2. Using Auto ID (Allows the device to assign PIN to next available User ID number)	1 (PIN) #
OR	2. Select Specific ID (Allows manager to define a specific User ID to associate the PIN to)
3. Exit	*

- 06 -

Tips for PIN Security (Only valid for 6 digits PIN):

For higher security we allow you to hide your correct PIN with other numbers up to a max of 10 digits.
 Example PIN: 123434
 You could use *(123434) ** or *(123434) (** can be any numbers from 0-9)
Note: This function for keypad version only

Add Master Fingerprint (By Specified ID: 99, Fingerprint version only)

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
1. Add Master Fingerprint	1 (99) # (Fingerprint) (Repeat Fingerprint) (Repeat Fingerprint again)
3. Exit	*

Add Visitor Users (Valid for Card/ PIN Users)

(User ID number is 990-999; PIN length: 4-6 digits except 8888)
 There are 10 groups Visitor PIN/card available, the users can be specified up to 10 times of usage, after a certain number of times, i.e. 5 times, the PIN/card become invalid automatically.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Add Card OR 2. Add PIN (Keypad version only)	1 (User ID) # (0-9) # (Read Card) / (Input 8/10/17 Digits Card Number) # 1 (User ID) # (0-9) # (PIN) # (0-9 means times of usage, 0=10 times)
3. Exit	*

Change PIN Users (PIN length: 4-6 digits except 8888) (Keypad version only)

Programming Step	Keystroke Combination
Change PIN	* (User ID) # (Old PIN) # (New PIN) # (Repeat New PIN) #

- 07 -

Delete Users

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Delete User - By Fingerprint/ Card/ PIN OR 2. Delete User - By ID number OR 2. Delete User - By Card number OR 2. Delete ALL Users	2 (Input Fingerprint) / (Read Card) / (Input PIN) # The users can be deleted continuously. 2 (User ID) # 2 (Input 8/10/17 Digits Card Number) # 2 (Master Code) #
3. Exit	*

Note: "Fingerprint" for Fingerprint version only "PIN" for Keypad version only

Set Relay Configuration

The relay configuration sets the behaviour of the output relay on activation.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Pulse Mode OR 2. Toggle Mode	3 (1-99) # (factory default) (The relay time is 1-99 seconds. (Default is 5 seconds) 3 # Sets the relay to ON/OFF Toggle mode
3. Exit	*

- 08 -

Simplified Instruction

Function Description	Operation
Enter the Programming Mode	* (Master Code) # then you can do the programming (123456 is the factory default master code)
Change the Master Code	0 - New Code - # - Repeat the New Code - # (code: 6 digits)
Add Card User	1 - Read Card - # (can add cards continuously)
Add Fingerprint User	1-Fingerprint- Repeat Fingerprint- Repeat Fingerprint Again- #
Add PIN User	1 - PIN - # (The PIN is any 4-6 digits except 8888 which is reserved)
Delete User	2-Fingerprint-# 2-Read Card-# 2-PIN-#
Exit from the Programming Mode	*
How to release the door	
Fingerprint User	Input Fingerprint
Card User	Read Card
PIN User	Input PIN #

Note: "Fingerprint" for Fingerprint version only "PIN" for Keypad version only

- 09 -

Set Access Mode

For Multi user access mode, the interval time of reading can not exceed 5 seconds, or else, the device will exit to standby automatically.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Fingerprint Access OR 2. Card Access OR 2. PIN Access OR 2. Multi User Access	4 0 # (Fingerprint version only) 4 1 # (factory default for RFID version only) 4 2 # (Keypad version only) 4 3 (2-9) # (Only after 2-9 valid users, the door be opened) 4 4 # (factory default for Fingerprint / Keypad version)
3. Exit	*

Set Strike-out Alarm

The strike-out alarm will engage after 10 failed entry attempts (Factory is OFF). It can be set to deny access for 10 minutes after engaging or disengage only after entering a valid Fingerprint/ card/ PIN or Master code/ fingerprint/ card.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Strike-Out OFF OR 2. Strike-Out ON	6 0 # (factory default) 6 1 # Access will be denied for 10 minutes (Exit button is still workable)
OR	2. Strike-Out ON (Alarm)
2. Strike-Out ON (Alarm)	6 2 #
Set Alarm Time	5 (0 ~ 3) # (factory default is 1 minute) Enter Master Code # or Master Fingerprint/ Card or valid user fingerprint / card / PIN to silence
3. Exit	*

- 10 -

Set Audible and Visual Response

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Disable Sound Enable Sound OR 2. LED Always OFF LED Always ON	7 0 # 7 1 # (factory default) 7 2 # 7 3 # (factory default)
3. Exit	*

Users Operation & Reset to Factory Default

- > **Open the door:** Read valid user fingerprint or user card or input valid user PIN #
- > **Remove Alarm:** Enter Master Code # or Master Fingerprint/ Card or valid user fingerprint / card / PIN
- > **Reset to factory default & Add Master Card:** Power off, press the Exit Button, hold it and power on, there will be two beeps, then release the exit button, the LED light turns into yellow, then read any 125KHz EM card/ 13.56MHz Mifare Card, the LED will turn into red, means reset to factory default successfully. Of the card reading, it is the Master Card.

Remarks:

- ① If no Master Card added, must press the Exit Button for at least 5 seconds before release.(this will make the previous registered Master Card invalid)
- ② Reset to factory default, the user's information is still retained.

- 11 -

Master Fingerprint/ Card Usage

(Master Card is not default accessory in the box, please add it by yourself if needed)

Using Master Fingerprint/ Card to add and delete users

Programming Step	Keystroke Combination
Add Fingerprint/ Card/ PIN Users	1. Input (Master Fingerprint / Card) or (Card) or (PIN #) Repeat step 2 for additional users 2. Input (Master Fingerprint / Card) again
Delete Fingerprint/ Card/ PIN Users	1. Input (Master Fingerprint/ Card) Twice within 5s 2. Input (Fingerprint) or (Card) or (PIN #) Repeat step 2 for additional users 3. Input (Master Fingerprint/ Card) again

Note: "Master Fingerprint" for Fingerprint version only

CONTROLLER MODE

The device can work as Controller, connected with the external Wiegand reader. (Factory default mode) — 7 7 #

Connection Diagram

Attention: Install a 1N4004 or equivalent diode is needed when use a common power supply, or the reader might be damaged. (1N4004 is included in the packing)

- 12 -

Set Wiegand Input Formats

Please set the Wiegand input formats according to the Wiegand output format of the external Reader.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Wiegand Input Bit	For EM Card: 8 (26- 44) # (factory default is 26bits) For Mifare Card: 8 0 (26-44, 56, 58) # (factory default is 34bits)
3. Disable Parity Bit Enable Parity Bit	8 0 # 8 1 # (factory default)
4. Exit	*

Notes: For connecting Wiegand readers with 32, 40, 56 bits output, need disable parity bits.

Programming

- > **Basic Programming is the same as Standalone Mode**
- > **There are some exceptions for your attention:**
- The device Connected with External Card Reader**
- If EM/Mifare card reader: users can be added/deleted on either the device or external reader.
- If HID card reader: users can only be added/deleted on external reader.
- The device Connected with Fingerprint Reader**
For example:
Connect SF1 as the fingerprint reader to the device.
Step 1: Add the Fingerprint (A) on SF1 (Please refer to SF1 manual)
Step 2: Add the same Fingerprint(A) on the device:

Programming Step	Keystroke Combination
1. Enter Program Mode: *	(Master Code) #
2. 1 (Press Fingerprint A once on SF1) # (ID auto allocated)	
OR 2. 1 (User ID) # (Press Fingerprint A on SF1) # (Select specific ID)	
3. Exit: *	

- 13 -

The device Connected with Keypad Reader

The keypad reader can be 4 Bits, 8 Bits (ASCII), or 10 Bits output format. Choose the below operation according to the PIN output format of your reader.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. PIN input bits	8 (4 or 8 or 10) # (factory default is 4 bits)
3. Exit	*

Remarks: 4 means 4 bits, 8 means 8 bits, 10 means 10 digits virtual number.

> **Add PIN Users:** To add PIN users, after enter into programming mode on the device, PIN(s) can be input/ added on either the device or the external Keypad Reader.

> **Delete PIN Users:** the same way as add users.

WIEGAND READER MODE

The device can work as Standard Wiegand Reader, connected to the third party Controller — 7 8 #

Connection Diagram

Notes:

- > When set into Wiegand Reader mode, nearly all settings in Controller Mode will become invalid, and Yellow wire will be redefined as below:
- Yellow wire: Buzzer control
- > If you need to connect Yellow wire: When the input voltage for Buzzer is low, it will sound.

- 14 -

Set Wiegand Output Formats

Please set the Wiegand output formats of Reader according to the Wiegand input formats of the Controller.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Wiegand output bits	For EM Card: 8 (26- 44) # (factory default is 26bits) For Mifare Card: 8 0 (26-44, 56, 58) # (factory default is 34bits) 8 (4 or 8 or 10) # (factory default is 4 bits)
PIN output bits	
3. Disable Parity Bit Enable Parity Bit	8 0 # 8 1 # (factory default)
4. Exit	*

Notes: For connecting Wiegand controller with 32, 40, 56 bits input, need disable parity bits.

ADVANCED APPLICATION

Collection Card Mode

After this mode turned on, all cards can open the lock. At the same time, the card is added to the device.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Collection Card Mode OFF OR 2. Collection Card Mode ON	9 2 # (factory default) 9 3 #
3. Exit	*

Reset the WIFI (After resetting, the device will be removed in APP)

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Update Master Code	9 (Master Code) #
3. Exit	*

- 15 -

Video Intercom Access

User Manual

- 16 -