How to use CDV-70QT (Simple Manual)




1. Connect with Smart phone

After connecting to a smartphone, it is possible to make a call, monitor the door camera, and notify an emergency. Before connecting to a smartphone, please install the mobile app and register as a member first.

* The product must be connected to Wi-Fi for account connection.


1-1. Connect with Smart phone

Before connecting, make sure that the product and the smartphone are connected to the same Wi-Fi.



01

Press Add Device On the main screen of the mobile app.



02

On the [Auto Scan] tab at the top, click Start scanning].

If the button is not activated, enable location access and Wi-Fi permission.



App Installation

Before connecting the product, depending on the smartphone OS, Google Play Store or App Store Search 'Commax Hey Call' and install the app. (*Supported operating systems: Android, iOS only)








03

If you place your smartphone near the product, it will be automatically detected.




04

The connection is completed when the discovered device is registered.

1-2. Invite family members

Invite your family members to use it together with your smartphone.



1-3. Register for invitation

You can add family members (members) to share by sending invitations.



** Before registering the invitation code, the family (member) must also install the "Commax Hey Call" mobile app.

Move the invitation code received via text message, etc. to [Home Management] → [With Family] to register and then use all functions on your smartphone.

2. Checking visitors with a smartphone

2-1. Make a visitor video call

If there is a visitor, a video call is possible through the mobile app connected to the product.









[Screen of Mobile App]

[Calling Screen]

01

When a visitor presses the doorbell, a 'Doorbell' notification is displayed on their smartphone.

2-2. Monitoring in front of my house

- You can monitor real-time video by selecting the door camera on the main screen of the mobile app.
- If there is an additionally connected CCTV, the same real-time monitoring function is supported.

02

You can make video calls with visitors in real time through the linked mobile app.

Additional Tips

Connect the door lock and open the door from the app.


** Door lock interlocking requires a specific module installation. For details, refer to the product user manual.


3. Using the Security mode

This product detects movement outside the front door and provides a function to save photos/videos, and it also enables emergency notifications through door open detection, so you can keep your home safe.

3-1. Motion detection notifications

To use the motion detection function, you need to change the environment settings of this product first.





Set whether to use motion detection in [Setting] \rightarrow [Recording/Wi-Fi] screen.

When motion is detected, you can also receive a notification on your smartphone and view the saved images.

* How notifications are displayed differs depending on the smartphone model.

3-2. Detecting door open

If you set the security emergency function, you can detect the door opening and receive a notification through the product and smartphone. In case of emergency, an emergency screen and siren are activated.

※ For security emergency settings, check the security sensor to be detected in the [Main Screen] → [Security] screen of the product and press the Execute button.

3-3. Setting a security password

The initial password is set to '1234' for the password used in case of a crime prevention situation. Please make changes after installing the product.

※ The password can be easily changed in the product [Settings] → [Others] → [Security password].
(If you lose the password you are using, execute [Initialize Settings] to change the initial password to '1234'.)

⁻ There may be differences depending on product and site specifications, and software optimization or screen may be changed without prior notice.