


Wireless Temperature and Humidity Detector User Manual

Product Description





Network Setting

1. Power on the product.




Rotate the battery cover counterclockwise to open it.



Install two AAA batteries.

 Press the reset button for 5s, the signal icon flashes, the detector is in network setting status.





- Press the button for 5s-10s, when signal icon flashes fast, release the button for network setting. It will last for 20s for network setting, and the signal icon keeps on flashing. If pressing for more than 10s, network
- setting is cancelled.

 The signal icon will stay to indicate network setting succeeds. If fails, the signal icon will disappear.

Installation Instructions

Installation method 1: Use a 3M sticker to affix the product to the target position. $\label{eq:continuous} I$



Installation method 2: Place the product on the support.



Technical Parameters

Wireless Technology	ZigBee		
Working Voltage	DC 3 V (Two AAA batteries)		
Transmission Frequency	2.4 GHz		
Working Temperature	–10°C to +55°C 0% to 99.9% RH		
Undervoltage Alarm	Supported		
Dimensions	ф61.2 mm x 23 mm		

Toxic or Hazardous Substances or Flements of this Product

	Toxic or Hazardous Substances or Elements					
Component Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr (VI))	Polybrominated biphenyls (PBBs)	Polybrom diphenyl (PBDE
LED	0	0	0	0	0	0
PCB	0	0	0	0	0	0
Cover and other	0	0	0	0	0	0

exceeds that stipulated in GB/T 26572.

This table complies with SJ/T 11364. Or indicates that the toxic or hazardous substance amount contained in all homogeneous materials of a component does not exceed that stipulated

in GB/T 26572. X: indicates that the toxic or hazardous substance amount contained in at least one of the homogeneous materials of a component

Warranty Certificate

Warranty policy:

- 1. If the product has quality problems within 7 days of the payment date, you can apply for a refund based on the invoice price or to
- replace with the same model or have it repaired.. 2. If the product has quality problems within 15 days of the payment date, you can apply to replace the product with he same model or
- have it repaired. 3. If the product has quality problems within 12 months of the payment date, you can apply to have it repaired.
- What is not covered under this warranty:
- 1. The product owner has no warranty certificate or the warranty
- service has expired.
- 2. Damage caused by improper use, maintenance, or storage 3. Damage caused by disassembly and repair without Tuya's
- authorization
- 4. Damage caused by force majeure
- 5. Normal discoloration and depreciation after the product has been used

User Form

Vendor Form

User information (Specify real information, Tuya promises

to use the information only for after-sales services.)

User information (Specify real information, Tuya promises to use the information only for after-sales services.)

Name	Name
Phone number	Phone number
Email	Email
Zip code	Zip code
Address	Address
Productinformation	Product information
Name Model	Name Model
Color Product SN	Color — Product SN
Service Return Replace Repair	Service Return Replace Repair
Fault symptoms	Fault symptoms
Handling date	Handling date
Maintenance personnel signature	Maintenance personnel signature